

INSTALLATION METHOD FOR MAIN STUD KITS

Part Number: 234-5608 **Application:** Chevy Gen III/LS Series small block

1. To ensure proper thread engagement and accurate torque readings, clean **ALL** threads in the block. Chase the threads if necessary with a Thread Chaser.
2. Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages, plus proper fit, length and dimension.
3. Screw the studs into the block "HAND TIGHT ONLY".

NOTE: LOCTITE MAY BE USED IF A PERMANENT MOUNTING OF THE STUDS IS PREFERRED. THE FASTENERS, HOWEVER, MUST BE TORQUED PRIOR TO THE LOCTITE SETTING UP.

4. Install the main caps and check for binding or misalignment.
5. Lubricate the stud threads and the nuts with ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT. Then install the nuts onto the studs and tighten them hand tight. **ARP recommends using the ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT that is provided with each kit as opposed to motor oil. This is due to higher friction on the studs as well as inconsistencies in the clamping force of the fasteners when motor oil or other low quality lubricants are used.**

PRELOAD (TORQUE) RECOMMENDATIONS

6. Following the manufacturers recommended torque sequence tighten the nuts and bolts in three equal steps to the specifications listed below with ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT.

Inner studs - 4.770 long 60 ft lbs

M8 side bolts 20 ft lbs (use RTV sealant under the head of bolt)

Outer studs - 4.550 long 50 ft lbs

Windage tray nuts 28 ft lbs

FOOTNOTE: When changing from factory fasteners to high strength fasteners, clamping force and tolerances will change, therefore it will be necessary to check the main bearing bores for proper size and out of round condition after installation of the studs and align hone the cylinder block if necessary. The main bores should always be align honed using the same fasteners and lubricant which will be installed during final engine assembly at the recommended preload.

Bolt Torque Sequence

